


www.falc.eu  
e-mail: info@falc.eu



via Proventa n.41 - Faenza (Ra) - ITALY -

☎ ++39 0546 29050

Fax ++39 0546 663986


## CATALOGO RICAMBI


Modello:

# Fresa Pieghevole Gamma

## 5000 - 6000


Rivenditore / Dealer / Händler / Concessionnaire





TAV. 739

RIDUTTORE T-331A R=1:1.35  
 FRESA GAMMA




|             |                       |                                   |
|-------------|-----------------------|-----------------------------------|
| <b>Falc</b> | <b>Tavola Ricambi</b> | <b>Fresa pieghevole GAMMA</b>     |
| pag.1       | n. 739 01/2011        | Scatola centrale T-331 - R=1:1,35 |

| Pos. | Codice | Descrizione |
|------|--------|-------------|
|------|--------|-------------|

|    |                 |   |   |
|----|-----------------|---|---|
|    | <b>90.0.069</b> | <b>Scatola COMPLETA<br/>T-331 - R=1:1,35<br/>cod. Comer 9.331.205.00<br/>Al rotore: 330 rpm</b> | <b>Complete Gearbox<br/>T-331 - R=1:1,35<br/>item Comer 9.331.205.00<br/>Rotor: 330 rpm</b> |
| 1  | 09.2.001        | Tappo con valvola ½   | Plug with valve ½   |
| 2  | 01.0.223        | Vite TE M12 L=40 - UNI5739 8.8  | Screw TE M12 L=40 - UNI5739 8.8   |
| 3  | 09.2.029        | Tappo conico esagono esterno ½  | Conical plug ½  |
| 4  | 8.5.2.01290     | Seeger per interni d 47 - UNI7437   | Seeger for int. d 47 - UNI7437  |
| 5  | 8.7.0.01362     | Cappello di chiusura 47x7   | Closing cap 47x7  |
| 6  | 05.0.042        | Seeger per alberi d 65 - UNI7435  | Seeger for shafts d 65 - UNI7435  |
| 7  | 8.0.1.02297     | Cuscinetto a sfere 6007   | Ball bearing 6007   |
| 8  | 07.0.080        | Paraolio Ba 35x52x7   | Oil sealer Ba 35x52x7   |
| 9  | 05.1.001        | Seeger per interni d 62 - UNI7437   | Seeger for int. d 62 - UNI7437  |
| 10 | 0.259.7500.00   | Spessore registro 35.3x48.0   | Shim 35.3x48.0  |
| 11 | 0.331.3200.00   | Albero attacco pompa (gruppo 2)   | Shaft for pump hitch (group 2)  |
| 12 | 2.331.1700.00   | Coperchio attacco pompa (gruppo 2)  | Cap for pump hitch (group 2)  |
| 13 | 0.331.6003.00   | Corona conica Z=28 M7 R.1 35  | Crownwheel Z=28 M7 R.1 35   |
| 14 | 06.1.006        | Cuscinetto rulli conici 30312   | Taper roller bearing 30312  |
| 15 | 0.126.7500.00   | Spessore registro 110x129 (SOM)   | Shim 110x129 (SOM)  |
| 16 | 0.331.0302.00   | Scatola   | Gearbox   |
| 17 | 8.7.1.01382     | Paraolio BASL 60x90x8   | Oil sealer BASL 60x90x8   |
| 18 | 0.331.7101.00   | Distanziale 64.8x80x50  | Spacer 64.8x80x50   |
| 19 | 01.0.204        | Vite TE M12 L=30 - UNI5739 - 8.8  | Screw TE M12 L=30 - UNI5739 - 8.8   |
| 20 | 06.1.062        | Cuscinetto rulli conici 30313   | Taper roller bearing 30313  |
| 21 | 09.2.208        | Tappo conico esagono incassato 3/8  | Conical plug 3/8  |
| 22 | 06.1.003        | Cuscinetto rulli conici 30213   | Taper roller bearing 30213  |
| 23 | 8.7.1.02388     | Paraolio baud4slx7 - 70x125x12  | Oil sealer baud4slx7 - 70x125x12  |
| 24 | 0.331.2000.00   | Albero calettato 1"3/4 Z=20   | Splined shaft 1"3/4 Z=20  |
| 25 | 0.331.1300.00   | Prolunga lunga  | Long jackshaft  |
| 26 | 09.2.023        | Tappo conico esagono esterno 3/8  | Conical plug 3/8  |
| 27 | 0.110.7500.00   | Spessore di registrazione 65.3x79.7   | Shim 65.3x79.7  |
| 28 | 0.267.7107.00   | Dado di registrazione M55x2   | Nut M55x2   |
| 29 | 0.331.1302.00   | Coperchio   | Cap   |
| 30 | 0.719.7500.00   | Spessore registrazione 108.0x118.0  | Shim 108.0x118.0  |
| 31 | 0.331.3001.00   | Albero uscita passante 1"3/4 Z=20   | Output through shaft 1"3/4 Z=20   |
| 32 | 8.7.3.00948     | Paraolio BA 65x100x10   | Oil sealer BA 65x100x10   |
| 33 | 0.248.7500.00   | Spessore registro 60.3x71.7   | Shim 60.3x71.7  |
| 34 | 09.1.004        | Rondella rame 1/2   | Copper washer   |
| 35 | 8.6.0.01113     | Prolunga per tappo olio 1/2   | Extension for oil cap 1/2   |
| 36 | 0.331.5000.00   | Pignone conico Z=23 M8 R=1.35   | Pinion Z=23 M8 R=1.35   |
|    |                 |   |   |
|    |                 |   |   |
|    |                 |   |   |





| MODELLO    | A      | CODICE                         |
|------------|--------|--------------------------------|
| GAMMA 5000 | 1018.8 | 97.20.53 CON PARAOLI 82X105X10 |
| GAMMA 6000 | 1518.8 | 97.20.54 CON PARAOLI 82X105X10 |

TAV. 801

TRASMISSIONE  
LATERALE

FALC



|             |                       |  |
|-------------|-----------------------|--|
| <b>Falc</b> | <b>Tavola Ricambi</b> | <b>Fresa pieghevole GAMMA</b>                      |
| pag.1       | <b>n. 801 10/2012</b> | <b>Trasmissione laterale con Paraoli 82x105x10</b> |


|  | Codice | Descrizione |
|--|--------|-------------|
|--|--------|-------------|

|    |              |  |
|----|--------------|--|
| 1  | 1.ER.000.225 | Guarnizione carter trasmissione<br><b>Case transmission gasket</b>       |
| 2  | 06.2.012     | Cuscinetto 21314<br><b>Bearing</b>                                       |
| 3  | 1.ER.000.222 | Guarnizione supporto trasmissione<br><b>Support transmission gasket</b>  |
| 4  | 05.1.008     | Seeger per interni D150 UNI 7437<br><b>Seeger for int. D150 UNI 7437</b> |
| 5  | 1.ER.000.231 | Ingranaggio trasmissione Z=28 M9<br><b>Transmission gear Z=28 M9</b>     |
| 6  | 03.1.014     | Ghiera GUK M60x2<br><b>Nut GUK M60x2</b>                                 |
| 7  | 7.IV.000.256 | Supporto lato trasmissione<br><b>Support transmission side</b>           |
| 8  | 7.IV.000.257 | Mozzo lato trasmissione<br><b>Hub transmission side</b>                  |
| 9  | 07.0.189     | Paraolio 82x105x12 (n.2)<br><b>Oil sealer 82x105x12 (n.2)</b>            |
| 10 | 1.ER.000.233 | Mozzo centrale con foro M16<br><b>Central hub with hole M16</b>          |
| 11 | 40010200     | Cuscinetto 33211<br><b>Bearing 33211</b>                                 |
| 12 | 1.ER.000.230 | Ingranaggio centrale Z=24 M9<br><b>Central gear Z=24 M9</b>              |
| 13 | 1.ER.000.229 | Ingranaggio Z=63<br><b>Gear Z=63</b>                                     |
| 14 | 40020006     | Seeger per esterni D180 UNI 7435<br><b>Seeger for ext. D180 UNI 7435</b> |
| 15 | 1.ER.000.223 | Guarnizione mozzo centrale<br><b>Central hub gasket</b>                  |
| 16 | 40021206     | Ghiera GUP M55x2<br>con grano M6x10                                      |
|    | 03.1.012     | Ghiera GUP M55x2<br><b>Nut GUP M55x2</b>                                 |
| 17 | 7.IV.000.328 | Assieme carter trasmissione M8-M9<br><b>Transmission case M8-M9</b>      |
| 18 | 1.ER.230.816 | Tromba completa 5000<br><b>Jackshaft 5000</b>                            |
|    | 1.ER.300.816 | Tromba completa 6000<br><b>Jackshaft 6000</b>                            |
| 19 | 1.ER.230.815 | Albero trasmissione 5000<br><b>Transmission shaft 5000</b>               |
|    | 1.ER.300.815 | Albero trasmissione 6000<br><b>Transmission shaft 6000</b>               |
| 20 | 40010200     | Cuscinetto 33211<br><b>Bearing 33211</b>                                 |
| 21 | 1.ER.000.228 | Ingranaggio Z=18 M8<br><b>Gear Z=18 M8</b>                               |

|  | Codice | Descrizione |
|--|--------|-------------|
|--|--------|-------------|

|    |              |  |
|----|--------------|--|
| 22 | 40021212     | Ghiera GUP M50x1.5<br><b>Nut GUP M50x1.5</b>                                       |
| 23 | 07.0.007     | Paraolio 50x72x10<br><b>Oil sealer 50x72x10</b>                                    |
| 24 | 40010202     | Cuscinetto 33010<br><b>Bearing 33010</b>   |
| 25 | 7.IV.000.284 | Distanziale in tubo D80<br><b>Tube spacer D80</b>                                  |
| 26 | 40023009     | OR 3193N per albero D50<br><b>OR 3192N for shaft D50</b>                           |
| 27 | 40029017     | Paraolio 80x64x8<br><b>Oil sealer 80x64x8</b>                                      |
| 28 | 40018003     | Anello RW80 UNI 7433-75<br><b>Ring RW80 UNI 7433-75</b>                            |
| 29 | 1.SQ.000.155 | Anello distanziale per tromba<br><b>Spacer ring for jackshaft</b>                  |
| 30 | 1.ER.000.224 | Guarnizione tromba<br><b>Jackshaft gasket</b>                                      |
| 31 | 40021405     | Tappo di livello e scarico olio<br><b>Level plug and oil blowoff</b>               |
| 32 | 40021404     | Tappo superiore di sfiato olio<br><b>Top breather</b>                              |
| 33 | 09.1.002     | Rondella da 3/8 in rame<br><b>Copper washer 3/8</b>                                |
| 34 | 40021409     | Tappo scarico magnetico M18x1.5 alluminio<br><b>Oil drain plug M18x1.5 alumin.</b> |
| 35 | 0.045162037  | Vite TE M16 L=35 UNI 5737<br><b>Screw TE M16 L=35 UNI 5737</b>                     |
| 36 | 04.0.006     | Rosetta grower M16 extrapesante<br><b>Spring washer M16 extraheavy</b>             |
| 37 | 01.1.152     | Vite TE M14x1.5 L=35 UNI 5740<br><b>Screw TE M14x1.5 L=35 UNI 5740</b>             |
| 38 | 04.0.005     | Rosetta grower M14 extrapesante<br><b>Spring washer M14 extraheavy</b>             |
| 39 | 01.1.102     | Vite TE M12x1.25 L=30 UNI 5740<br><b>Screw TE M12x1.25 L=30 UNI 5740</b>           |
| 40 | 04.0.004     | Rosetta grower M12<br><b>Spring washer M12</b>                                     |
| 41 | 02.5.002     | Dado M12x1.25 Metalbloc ZG<br><b>Metalbloc ZG nut M12x1.25</b>                     |
| 42 | 01.1.052     | Vite TE M10x1.25 L=30 UNI 5740<br><b>Vite TE M10x1.25 L=30 UNI 5740</b>            |
| 43 | 02.5.001     | M10x1.25 Metalbloc<br><b>M10x1.25 Metalbloc</b>                                    |

**FALC**



**FRESA GAMMA  
IMPIANTO RICIRCOLO OLIO**

**TAV.734**




|             |                       |                               |
|-------------|-----------------------|-------------------------------|
| <b>Falc</b> | <b>Tavola Ricambi</b> | <b>Fresa pieghevole GAMMA</b> |
| pag.1       | n. 734 12/2010        | Impianto ricircolo olio       |

| Pos. | Codice   | Descrizione   |   |
|------|----------|---|---|
| 1    | 09.0.319 | Pompa   | Pump  |
| 2    | 09.0.506 | Mozzo MO 2/14   | Hub   |
| 3    | 09.0.405 | Filtro FBO FLA 100 (90 micron)                            | Filter FBO FLA 100 (90 micron)                            |
| 4    | 69.40.57 | Tubo SAE 100 R1 3/4" - F.C.90° 3/4"<br>F.C.90° 3/4" L=460 | Tube SAE 100 R1 3/4" - F.C.90° 3/4"<br>F.C.90° 3/4" L=460 |
| 5    | 97.10.42 | Tubo SAE 100 R1 1/2" - F.C.90° 1/2"<br>F.D. 3/4" L=750    | Tube SAE 100 R1 1/2" - F.C.90° 1/2"<br>F.D. 3/4" L=750    |
| 6    | 25.10.62 | Tubo SAE 100 R1 3/4" - F.C. 90° 3/4"<br>F.D. 3/4" L=850   | Tube SAE 100 R1 3/4" - F.C. 90° 3/4"<br>F.D. 3/4" L=850   |
| 7    | 97.10.43 | Tubo SAE 100 R1 3/4" - F.C.90° 3/4"<br>F.D. 3/4" L=750    | Tube SAE 100 R1 3/4" - F.C.90° 3/4"<br>F.D. 3/4" L=750    |
| 8    | 09.1.104 | Nipplo 3/4" - 3/4"  | Nipple 3/4" - 3/4"  |
| 9    | 09.1.103 | Nipplo 1/2" - 1/2"  | Nipple 1/2" - 1/2"  |
| 10   | 09.1.154 | Nipplo riduzione 3/4" - 1/2"                              | Reduction nipple 3/4" - 1/2"                              |
| 11   | 09.1.004 | Rondella rame 1/2"  | Copper washer 1/2"  |
| 12   | 09.1.006 | Rondella rame 3/4"  | Copper washer 3/4"  |
| 13   | 09.2.007 | Tappo conico 3/4" con esagono esterno                     | Conical plug 3/4" ext.exagon                              |
| 14   | 09.0.409 | ( <del>09.0.094</del> ) Cartuccia CR100                   | ( <del>09.0.094</del> ) Cartridge CR100                   |
| 15   | 01.2.109 | Vite TCEI M8 L=25 tf UNI 5931<br>classe 8.8               | Screw TCEI M8 L=25 tf UNI 5931<br>class 8.8               |
| 16   | 01.0.102 | Vite TE M8 L=20 tf UNI 5739<br>classe 8.8                 | Screw TE M8 L=20 tf UNI 5739<br>class 8.8                 |
|      |          |   |   |
|      |          |   |   |
|      |          |   |   |



# FALC



TAV.469

IMPIANTO OLEODINAMICO

|             |                       |                                     |
|-------------|-----------------------|-------------------------------------|
| <b>Falc</b> | <b>Tavola Ricambi</b> | <b>Erpice / P – Fresa Gamma / P</b> |
| pag.1       | <b>n. 469 09/2010</b> | <b>Impianto Oleodinamico</b>        |

| Pos. | Codice | Descrizione |
|------|--------|-------------|
|------|--------|-------------|

|    |          |  |  |
|----|----------|--|--|
| 1  | 73.10.71 | Martinetto doppio effetto sollevamento macchina (alessaggio 120) | Double effect jack (cylinder bore 120)           |
| 2  | 72.00.38 | Martinetto ganci   | Hydraulic jack                                   |
| 3  | 72.10.38 | Tubo SAE100R2AT 3/8"-M.D.1/2"-F.D.3/8" - L=2000                  | Tube SAE100R2AT 3/8"-M.D.1/2"-F.D.3/8" - L=2000  |
| 4  | 72.10.39 | Tubo SAE100R2AT 3/8"-F.C.90°3/8"-O.3/8" - L=1300                 | Tube SAE100R2AT 3/8"-F.C.90°3/8"-O.3/8" - L=1300 |
| 5  | 72.10.18 | Tubo SAE100R1AT 1/4"-F.C.90°3/8"-O.1/4" - L=580                  | Tube SAE100R1AT 1/4"-F.C.90°3/8"-O.1/4" - L=580  |
| 6  | 72.10.19 | Tubo SAE100R1AT 1/4"-F.D.3/8"-O.1/4" - L=500                     | Tube SAE100R1AT 1/4"-F.D.3/8"-O.1/4" - L=500     |
| 7  | 09.0.540 | Valvola di sequenza VDSRL 5-38 APP - Taratura 50 bar             | Valve VDSRL 5-38 APP – cal. 50 bar               |
| 8  | 09.0.541 | Valvola di sequenza VDSRL 5-38 APP - Taratura 150 bar            | Valve VDSRL 5-38 APP – cal. 150 bar              |
| 9  | 09.1.509 | Attacco rapido conico parte maschio 1/2" art.1877                | Conical quick hitch 1/2" art.1877                |
| 10 | 09.1.301 | Raccordo a T maschio 3/8"  | Male "T" joint 3/8"                              |
| 11 | 09.0.521 | Giunzione girevole M 3/8"- F 3/8"                                | Rotating joint M 3/8"- F 3/8"                    |
| 12 | 09.0.522 | Giunzione girevole F 3/8"- F 3/8"                                | Rotating joint F 3/8"- F 3/8"                    |
| 13 | 09.1.102 | Nipplo 3/8"-3/8"   | Nipple 3/8"-3/8"                                 |
| 14 | 09.1.054 | Vite forata 1/4"   | Drilled screw 1/4"                               |
| 15 | 09.1.051 | Vite forata 3/8"   | Drilled screw 3/8"                               |
| 16 | 09.0.538 | Colonna h=25 M 3/8" - F 3/8"                                     | Stud bolt h=25 M 3/8" - F 3/8"                   |
| 17 | 09.1.001 | Rondella in rame 1/4"  | Copper washer 1/4"                               |
| 18 | 09.1.002 | Rondella in rame 3/8"  | Copper washer 3/8"                               |
| 19 | 09.1.004 | Rondella in rame 1/2"  | Copper washer 1/2"                               |
| 20 | 09.2.048 | Tappo TF 12  | Cover TF 12                                      |
| 21 | 73.20.59 | Attacco a 3 punti  | 3 point linkage                                  |
| 22 | 73.00.64 | Gancio   | Hook   |
| 23 | 73.00.66 | Perno pistone e gancio   | Piston pin and hook                              |
| 24 | 73.00.68 | Perno di sicurezza lato erpice                                   | Safety pin harrow side                           |
| 25 | 73.10.72 | Perno pistone lato erpice  | Piston pin harrow side                           |
| 26 | 73.10.73 | Boccola bloccaggio pistone                                       | Piston blocking bush                             |
| 27 | 72.00.17 | Boccola pistone  | Bush   |
| 30 | 01.1.173 | Vite TE M14x1,5 L=70 pf UNI 5738                                 | Screw TE M14x1,5 L=70 pfUNI5738                  |
| 31 | 02.5.003 | Dado metalbloc M14x1,5 h=12                                      | Metalbloc nut M14x1,5 h=12                       |
| 32 | 05.2.211 | Spina elastica a spirale 12x60 UNI 6875                          | Spiral split pin12x60 UNI 6875                   |
| 33 | 04.1.010 | Rosetta d 40 40,5x80x5 zincata                                   | washer d 40 40,5x80x5 galv.                      |
| 34 | 09.2.508 | Ingrassatore dritto a spillo M8                                  | Straight greaser M8                              |
| 35 | 01.0.063 | Vite TE M6 L=90 pf UNI 5737                                      | Screw TE M6 L=90 pf UNI 5737                     |
| 36 | 02.2.010 | Dado autobloccante M6 UNI 7473                                   | Selflock. nut M6 UNI 7473                        |
| 37 | 01.0.602 | Vite TE M30 L=110 tf UNI 5739                                    | Screw TE M30 L=110 tf UNI 5739                   |
| 38 | 02.0.411 | Dado esagonale M30 h=24 UNI 5588                                 | Ex.standard nut M30 h=24 UNI 5588                |
| 39 | 73.10.76 | Rosetta d 40,5x60x5 zincata                                      | Washer d 40,5x60x5 galv.                         |
| 40 | 05.5.003 | Spinotto d 10 – Zincato  | Pin d 10 – galv.                                 |
| 41 | 09.1.453 | Valvola di blocco – Taratura 150 bar                             | Blocking valve – 150 bar                         |
| 42 | 09.1.454 | Valvola di blocco – Taratura 450 bar                             | Blocking valve – 450 bar                         |



# TAV.736

DIS.73.20.50 MARTINETTO

COD.09.1.002

RONDELLA 3/8

COD.09.1.051 VITE

FORATA 3/8

DIS.73.20.54 DADO M45x2 H=15


DIS.73.20.51 TESTA FILETTATA M45x2

COD.01.5.114 GRANO M12 L=20  
PUNTA CONICA UNI 5927

DIS.73.10.71 MARTINETTO COMPLETO

PER MACCHINE PRODOTTE FINO A DICEMBRE 2001: KIT GUARNIZIONI COD.Q07.000.0000008  
PER MACCHINE PRODOTTE DA GENNAIO 2002: KIT GUARNIZIONI COD.SV.2000001610

420




TUBO PER VALVOLA  
COD.09.0.545

OCCHIO 3/8

## ERPICE / P GAMMA / P


# FALC





**FRESA  
PIEGHEVOLE  
GAMMA**

**TAV.800**





|             |                       |                               |
|-------------|-----------------------|-------------------------------|
| <b>Falc</b> | <b>Tavola Ricambi</b> | <b>Fresa pieghevole GAMMA</b> |
| pag.1       | <b>n. 800 10/2012</b> | <b>Telaio</b>                 |

|    | Codice   | Descrizione   |
|----|----------|---|
| 1  | 73.20.59 | Attacco 3p pieghevole<br><b>Folding 3 point hitch</b>   |
| 2  | 05.3.012 | Copiglia d 5 L=40 UNI 1336<br><b>Split pin d 5 L=40 UNI 1336</b>                                    |
| 3  | 97.20.13 | Flangia fiancata centrale DX<br><b>RH Central side flange</b>                                       |
|    | 97.20.14 | Flangia fiancata centrale SX<br><b>LH Central side flange</b>                                       |
| 4  | 73.00.02 | Perno snodo L=214<br><b>Joint pin L=214</b>   |
| 5  | 97.20.24 | Raschiatore centrale<br><b>Central scraper</b>  |
| 6  | 69.30.54 | Fiancata posteriore<br><b>Rear side</b>   |
| 7  | 73.10.40 | Perno attacco 3p inferiore<br><b>Lower 3 point linkage pin</b>                                      |
| 8  | 51.70.29 | Perno cerniera e regolazione rullo<br>senza manovella<br><b>Roller adjustment pin without crank</b> |
| 9  | 67.02.69 | Spina inferiore 3a cat.<br><b>Bottom pin III cat.</b>   |
| 10 | 67.02.67 | Spina superiore 3a cat.<br><b>Top pin III cat.</b>  |
| 11 | 97.00.70 | Distanziale superiore L=31<br><b>Upper spacer L=31</b>  |
| 12 | 97.00.71 | Distanziale superiore L=51<br><b>Upper spacer L=51</b>  |
| 13 | 97.00.69 | Supporto protezione PTO esterne<br><b>External PTO guard support</b>                                |
| 14 | 20.70.68 | Protezione PTO esagonale<br><b>Exagonal pto guarding</b>  |
| 15 | 73.10.33 | Protezione cardano laterale DX<br><b>RH lateral cardan guard</b>                                    |
| 16 | 73.10.37 | Protezione cardano laterale SX<br><b>LH lateral cardan guard</b>                                    |
| 17 | 73.10.68 | Barra di sicurezza<br><b>Safety bar</b>   |
| 18 | 97.10.57 | Attacco DX 5000<br><b>RH linkage 5000</b>   |
|    | 97.00.98 | Attacco DX 6000<br><b>RH linkage 6000</b>   |
| 19 | 97.10.58 | Attacco SX 5000<br><b>LH linkage 5000</b>   |
|    | 97.00.99 | Attacco SX 6000<br><b>LH linkage 6000</b>   |
| 20 | 97.20.57 | Braccio dente centrale<br><b>Central tine arm</b>   |
| 21 | 69.50.78 | Attacco 3p inferiore 3° cat.<br><b>3 point lower linkage III cat.</b>                               |
| 22 | 24.40.40 | Vomerino<br><b>Share</b>  |
| 23 | 01.5.401 | Vite TPSQST M12 L=60 UNI 6104<br><b>Screw TPSQST M12 L=60 UNI 6104</b>                              |

|    | Codice   | Descrizione   |
|----|----------|---|
| 24 | 02.0.404 | Dado esagonale normale M12 h=10<br>UNI 5588<br><b>Exagonal standard nut M12 h=10<br/>UNI 5588</b> |
| 25 | 97.10.33 | Supporto attacchi laterali<br><b>Side linkages support</b>  |
| 26 | 97.10.32 | Cavallotto<br><b>Rod</b>  |
| 27 | 97.20.59 | Telaio DX 5000<br><b>RH frame 5000</b>  |
|    | 97.20.33 | Telaio DX 6000<br><b>RH frame 6000</b>  |
| 28 | 97.20.60 | Telaio SX 5000<br><b>LH frame 5000</b>  |
|    | 97.20.34 | Telaio SX 6000<br><b>LH frame 6000</b>  |
| 29 | 97.10.51 | Carter esterno DX 5000<br><b>RH external case 5000</b>  |
|    | 97.00.64 | Carter esterno DX 6000<br><b>RH external case 6000</b>  |
| 30 | 97.10.52 | Carter centrale DX 5000<br><b>RH central case 5000</b>  |
|    | 97.00.65 | Carter centrale DX 6000<br><b>RH central case 6000</b>  |
| 31 | 97.10.53 | Carter centrale SX 5000<br><b>LH central case 5000</b>  |
|    | 97.00.66 | Carter centrale SX 6000<br><b>LH central case 6000</b>  |
| 32 | 97.10.54 | Carter esterno SX 5000<br><b>LH external case 5000</b>  |
|    | 97.00.67 | Carter esterno SX 6000<br><b>LH external case 6000</b>  |
| 33 | 97.10.90 | Sportello carter DX<br><b>RH case door</b>  |
| 34 | 97.10.91 | Sportello carter SX<br><b>LH case door</b>  |
| 35 | 04.1.004 | Rosetta 15x31x3<br><b>Washer 15x31x3</b>  |
| 36 | 02.4.004 | Dado metalbloc M14 h=12<br><b>Metalbloc nut M14 h=12</b>  |
| 37 | 24.60.00 | Asta per ammortizzatori carter<br>mobile<br><b>Shock absorber rod</b>                             |
| 38 | 24.02.19 | Boccola snodata per asta d 18<br><b>Articulated bush for rod d 18</b>                             |
| 39 | 24.01.81 | Perno braccio per molla carter L=100<br><b>Case rod arm pin</b>                                   |
| 40 | 26.50.40 | Distanziale bracci<br><b>Arms spacer</b>  |
| 41 | 26.50.39 | Braccio ammortizzatore L=284<br><b>Shock absorber arm L=284</b>                                   |
| 42 | 201      | Molla attacco carter<br><b>Case hitch spring</b>  |

|             |                       |                               |
|-------------|-----------------------|-------------------------------|
| <b>Falc</b> | <b>Tavola Ricambi</b> | <b>Fresa pieghevole GAMMA</b> |
| pag.2       | n. 800 10/2012        | Telaio                        |

|  | Codice | Descrizione |
|--|--------|-------------|
|--|--------|-------------|

|    |          |  |
|----|----------|--|
| 43 | 97.20.44 | Perno carter 5000<br><b>Case pin 5000</b>  |
|    | 97.20.61 | Perno carter 6000<br><b>Case pin 6000</b>  |
| 44 | 97.20.53 | Compl. trasmissione laterale 5000<br><b>Side drive 5000</b>  |
|    | 97.20.54 | Compl. trasmissione laterale 6000<br><b>Side drive 6000</b>  |
| 45 | 97.00.50 | Protezione carter<br><b>Case guarding</b>  |
| 46 |          | Albero cardanico laterale<br>cod. D.S9N.091.FX.017.001<br><b>Side cardan shaft<br/>item D.S9N.091.FX.017.001</b>   |
| 47 | 73.20.60 | Piastra superiore<br><b>Top plate hitch</b>  |
| 48 | 97.20.22 | Coperchio<br><b>Cap</b>  |
| 49 | 01.0.223 | Vite TE M12 L=40 tf UNI 5739<br><b>Screw TE M12 L=40 tf UNI 5739</b>   |
| 50 | 97.20.30 | Supporto rotore lato opposto<br>trasmissione<br><b>Rotor support opp. transmission side</b>                        |
| 51 | 97.20.31 | Mozzo rotore lato opposto<br>trasmissione<br><b>Rotor hub opp. transmission side</b>                               |
| 52 | 25.00.66 | Guarnizione supporto rotore lato<br>opposto trasmissione<br><b>Rotor support gasket opp.<br/>transmission side</b> |
| 53 | 70.01.06 | Ghiera da acciaccare M60x1.5 h=20<br><b>Ring M60x1.5 h=20</b>  |
| 54 | 07.0.025 | Paraolio 80x110x16 COMBI<br><b>Oil sealer 80x110x16 COMBI</b>  |
| 55 | 05.1.007 | Seeger per interni d 140 s=4<br>UNI 7437<br><b>Seeger for int. d 140 s=4 UNI 7437</b>                              |
| 56 | 09.2.504 | Ingrassatore dritto a spillo M10<br><b>Straight greaser M10</b>  |
| 57 | 06.2.002 | Cuscinetto 21313 E<br><b>Bearing 21313 E</b>   |
| 58 |          | Scatola<br><b>Gearbox</b>  |
| 59 | 01.1.152 | Vite TE M14x1,5 L=35 tf UNI 5740<br><b>Screw TE M14x1,5 L=35 tf UNI<br/>5740</b>                                   |
| 60 | 02.5.003 | Dado METALBLOC M14x1,5 h=12<br><b>METALBLOC nut M14x1,5 h=12</b>   |
| 61 | 01.0.155 | Vite TE M10 L=30 tf UNI 5739<br><b>Screw TE M10 L=30 tf UNI 5739</b>   |
| 62 | 02.4.002 | Dado metalbloc M10 h=9<br><b>Metalbloc nut M10 h=9</b>   |
| 63 | 01.1.152 | Vite TE M14x1,5 L=35 tf UNI 5740<br><b>Screw TE M14x1,5 L=35 tf UNI<br/>5740</b>                                   |

|  | Codice | Descrizione |
|--|--------|-------------|
|--|--------|-------------|

|    |          |  |
|----|----------|--|
| 64 | 01.1.154 | Vite TE M14x1,5 L=45 tf UNI 5740<br><b>Screw TE M14x1,5 L=45 tf UNI<br/>5740</b>                               |
| 65 | 01.1.153 | Vite TE M14x1,5 L=40 tf UNI 5740<br><b>Screw TE M14x1,5 L=40 tf UNI<br/>5740</b>                               |
| 66 | 04.1.601 | Rosetta elastica conica 15x32x4<br>UNI 8837<br><b>Conical spring washer 15x32x4<br/>UNI 8837</b>               |
| 67 | 01.0.121 | Vite TE M8 L=16 tf<br>UNI 5739 zincata<br><b>Screw TE M8 L=16 tf<br/>UNI 5739 galvanized</b>                   |
| 68 | 04.0.006 | Grower d 16 serie pesante<br><b>Spring washer d 16 heavy series</b>  |
| 69 | 01.1.205 | Vite TE M16x1,5 L= 45 tf<br>UNI 5740 cl. 10.9<br><b>Screw TE M16x1,5 L= 45 tf<br/>UNI 5740 cl. 10.9</b>        |
| 70 | 01.0.171 | Vite TE M10 L=20 tf<br>UNI 5739 zincata<br><b>Screw TE M10 L=20 tf<br/>UNI 5739 galvanized</b>                 |
| 71 | 04.1.201 | Rosetta d 10 10,5x21x2<br>UNI 6593 cat.C zincata<br><b>Washer d 10 10,5x21x2<br/>UNI 6593 cat.C galvanized</b> |
| 72 | 04.1.226 | Rosetta d 8 9x24x2<br>UNI 6593 cat.C zincata<br><b>Washer d 8 9x24x2<br/>UNI 6593 cat.C galvanized</b>         |
| 73 | 01.0.401 | Vite TE M20 L= 45 tf UNI 5739<br><b>Screw TE M20 L= 45 tf UNI 5739</b>   |
| 74 | 04.1.203 | Rosetta M20 21x37x3 UNI 6592<br>Cat.A DIN 125<br><b>Washer M20 21x37x3 UNI 6592<br/>Cat.A DIN 125</b>          |
| 75 | 01.0.301 | Vite TE M16 L= 30 tf UNI 5739<br><b>Screw TE M16 L= 30 tf UNI 5739</b>   |
| 76 | 04.1.202 | Rosetta M16 17x30x3<br>UNI 6592 CAT.A DIN 125<br><b>Washer M16 17x30x3<br/>UNI 6592 CAT.A DIN 125</b>          |
| 77 | 01.0.217 | Vite TE M12 L=90 pf UNI 5737<br><b>Screw TE M12 L=90 pf UNI 5737</b>   |
| 78 | 02.2.003 | Dado autobloccante M12 h=14,8<br>UNI 7473<br><b>Selflocking nut M12 h=14,8<br/>UNI 7473</b>                    |
| 79 | 05.3.402 | Spina a scatto d10 art.104<br><b>Release pin d10 art.104</b>   |
| 80 | 01.0.121 | Vite TE M8 L=16 tf UNI 5739<br><b>Screw TE M8 L=16 tf UNI 5739</b>   |




|             |                       |                               |
|-------------|-----------------------|-------------------------------|
| <b>Falc</b> | <b>Tavola Ricambi</b> | <b>Fresa pieghevole GAMMA</b> |
| pag.3       | <b>n. 800 10/2012</b> | <b>Telaio</b>                 |

|    | Codice   | Descrizione  |
|----|----------|--|
| 81 | 01.0.280 | Vite TE M14 L=40<br>UNI 5739 zincata<br><b>Screw TE M14 L=40 UNI 5739<br/>galvanized</b>                   |
| 82 | 02.4.004 | Dado metalbloc M14 h=12<br><b>Metalbloc nut M14 h=12</b>   |
| 83 | 04.1.234 | Rosetta d.14 16x42x3<br>UNI 6593 cat.C zincata<br><b>Washer d.14 16x42x3<br/>UNI 6593 cat.C galvanized</b> |
| 84 | 70.01.17 | Ghiera da acciaccare M45x1,5 h=18<br><b>Ring M45x1,5 h=18</b>  |
| 85 | 04.1.218 | Rosetta d 45 46x85x7<br>UNI 6592 cat.C<br><b>Washer d 45 46x85x7<br/>UNI 6592 cat.C</b>                    |
| 86 | 01.1.218 | Vite TE M16x1,5 L=50 pf UNI 5738<br><b>Screw TE M16x1,5 L=50 pf UNI<br/>5738</b>                           |
| 87 | 01.1.216 | Vite TE M16x1,5 L=100 pfUNI 5738<br><b>Screw TE M16x1,5 L=100 pfUNI<br/>5738</b>                           |
| 88 | 02.3.004 | Dado autobloc. M16x1,5 h=18<br>UNI 7473<br><b>Selflocking nut M16x1,5 h=18<br/>UNI 7473</b>                |
| 89 | 05.3.202 | Copiglia a molla d 4 art.114<br><b>Split pin d 4 art.114</b>   |
| 90 | 01.0.141 | Vite TE M8 L=55 p.f.<br>UNI 5737 zincata<br><b>Screw TE M8 L=55 p.f.<br/>UNI 5737 galvanized</b>           |
| 91 | 01.0.142 | Vite TE M8 L=80 p.f.<br>UNI 5737 zincata<br><b>Screw TE M8 L=80 p.f.<br/>UNI 5737 galvanized</b>           |
| 92 | 02.4.005 | Dado metalbloc M16 h=14<br><b>Metalbloc nut M16 h=14</b>   |
| 93 | 05.3.401 | Spina a scatto d 5 art.99<br><b>Release pin d 5 art.99</b>   |
| 94 | 01.1.151 | Vite TE M14x1,5 L=30 tf UNI 5740<br><b>Screw TE M14x1,5 L=30 tf UNI<br/>5740</b>                           |
| 95 | 01.1.106 | Vite TE M12x1,25 L=40 tf UNI5740<br><b>Screw TE M12x1,25 L=40 tf<br/>UNI5740</b>                           |
| 96 | 02.5.002 | Dado metalbloc M12x1,25 h=11<br><b>Metalbloc nut M12x1,25 h=11</b>   |
| 97 | 04.1.207 | Rosetta M12 13x24x2,5 UNI 6592<br>CAT.A<br><b>Washer M12 13x24x2,5 UNI 6592<br/>CAT.A</b>                  |
| 98 | 59.00.52 | Spina dente<br><b>Tine pin</b>   |
|    |          |  |

|     | Codice   | Descrizione  |
|-----|----------|--|
| 99  | 05.3.203 | Copiglia a molla d 5 art.116<br><b>Split pin d 5 art.116</b>           |
| 100 | 01.0.421 | Vite TE M20 L= 80 pf UNI 5737<br><b>Screw TE M20 L= 80 pf UNI 5737</b> |
| 101 | 02.4.008 | Dado metalbloc M20 h=19<br><b>Metalbloc nut M20 h=19</b>               |
| 102 |          |  |
| 103 |          |  |
| 104 |          |  |
| 105 |          |  |

# FALC





## FRESA GAMMA ROTORI

**TAV.804**

|             |                       |                               |
|-------------|-----------------------|-------------------------------|
| <b>Falc</b> | <b>Tavola Ricambi</b> | <b>Fresa pieghevole GAMMA</b> |
| pag.1       | <b>n. 804 10/2012</b> | <b>Rotori</b>                 |

| Pos. | Codice   | Descrizione  |  |
|------|----------|--|--|
| 1    | 97.10.22 | Rotore rotoking DX 5000<br>Rotore rotoking DX 6000   | Rotoking rotor RH 5000<br>Rotoking rotor RH 6000     |
| 2    | 97.10.23 | Rotore rotoking SX 5000<br>Rotore rotoking SX 6000   | Rotoking rotor LH 5000<br>Rotoking rotor LH 6000     |
| 3    | 24.01.95 | Dente rotoking piegato DX                            | RH bent tine rotoking                                |
| 4    | 24.01.96 | Dente rotoking piegato SX                            | LH bent tine rotoking                                |
| 5    | 24.01.31 | Dente rotoking                                       | Rotoking tine  |
| 6    | 26.40.02 | Vite M10 L=60 p.f. fissaggio dente                   | Screw M10 L=60 p.f. tine fixing                      |
| 7    | 02.2.002 | Dado autobloccante M10 h=12,3<br>UNI 7473            | Selflocking nut M10 h=12,3<br>UNI 7473               |
| 8    | 01.1.212 | Vite TE M16x1,5 L=90 p.f.<br>UNI 5738                | Screw TE M16x1,5 L=90 p.f.<br>UNI 5738               |
| 9    | 97.20.49 | Zappa centrale+esterna DX h=73                       | RH central+external hoe h=73                         |
| 10   | 97.20.50 | Zappa centrale+esterna SX h=73                       | LH central+external hoe h=73                         |
| 11   | 97.10.85 | Rotore FRESA 5000<br>Rotore FRESA 6000               | Hoes rotor 5000 rotor<br>Hoes rotor 6000 rotor       |
| 12   | 25.03.26 | Zappa DX h=145                                       | RH hoe h=145   |
| 13   | 25.03.27 | Zappa SX h=145                                       | LH hoe h=145   |
| 14   | 24.50.70 | Vite TE M16x1,5 L=45 p.f.<br>classe 10.9             | Screw TE M16x1,5 L=45 p.f.<br>class 10.9             |
| 15   | 02.5.004 | Dado metalbloc M16x1,5 h=14                          | Metalbloc nut M16x1,5 h=14                           |
| 16   | 04.0.006 | Grower serie pesante d 16                            | Spring washer heavy d 16                             |
| 17   | 97.20.51 | Zappa centrale+esterna DX h=120                      | RH central+external hoe h=120                        |
| 18   | 97.20.52 | Zappa centrale+esterna SX h=120                      | LH central+external hoe h=120                        |
| 19   | 97.00.94 | Anello centraggio lato trasmissione                  | Centering ring side transmission                     |
| 20   | 04.0.006 | Grower d 16 serie pesante                            | Spring washer heavy d 16                             |
| 21   | 01.1.205 | Vite TE M16x1,5 L= 45 tf –<br>UNI 5740 - classe 10.9 | Screw TE M16x1,5 L= 45 tf –<br>UNI 5740 - class 10.9 |
| 22   |          |  |  |
| 23   |          |  |  |
| 24   |          |  |  |





# FRESA GAMMA RULLO GABBIA 8+8 TUBI


TAV.802

|             |                       |                                |
|-------------|-----------------------|--------------------------------|
| <b>Falc</b> | <b>Tavola Ricambi</b> | <b>Fresa Pieghevole GAMMA</b>  |
| pag.1       | <b>n. 802 10/2012</b> | <b>Rullo Gabbia 8 + 8 tubi</b> |

| Pos. | Codice   | Descrizione                          |                                       |
|------|----------|--------------------------------------|---------------------------------------|
| 18   | 97.10.89 | Rullo gabbia 8                       | Cage roller 8 bars                    |
| 19   | 97.10.89 | Rullo gabbia 8 + 8 tubi - MONTATI    | Cage roller 8 + 8 bars - ASSEMBLED    |
| 20   | 97.10.20 | Coperchio supporto centrale          | Central support cap                   |
| 21   | 97.10.00 | Braccio esterno rullo DX             | Roller's external arm RH              |
| 22   | 97.10.01 | Braccio esterno rullo SX             | Roller's external arm RH              |
| 23   | 97.20.37 | Braccio centrale rullo DX            | Roller's central arm RH               |
| 24   | 97.20.38 | Braccio centrale rullo SX            | Roller's central arm RH               |
| 29   | 06.4.004 | Cuscinetto UCF 210                   | Bearing UCF 210                       |
| 30   | 05.0.031 | Seeger per esterni d 50 s=2 UNI 7435 | Seeger for external d 50 s=2 UNI 7435 |
| 31   | 01.0.257 | Vite TE M14 L=55 p.f. UNI 5737       | Screw TE M14 L=55 p.f. UNI 5737       |
| 34   | 02.4.004 | Dado metalbloc M14 h=12              | Metalbloc nut M14 h=12                |
| 40   | 06.2.015 | Cuscinetto 22210E                    | Bearing 22210E                        |
| 41   | 07.0.180 | Paraolio 62x90x10                    | Oil sealer 62x90x10                   |
| 42   | 05.1.003 | Seeger per interni d 90 s=3 UNI 7437 | Seeger for int. D 90 s=3 UNI 7437     |
| 43   | 09.2.508 | Ingrassatore dritto M8               | Straight greaser M8                   |
|      |          |                                      |                                       |
|      |          |                                      |                                       |
|      |          |                                      |                                       |



# USER AND MAINTENANCE MANUAL



## INDEX

- 1 General indications
- 2 Conditions for the operator
- 3.1 General conditions of use
- 3.2. Connection of rotary tiller to the tractor
- 3.3. Disconnection of the rotary tiller to the tractor
- 3.4. Rotary tillers C-D-E: reducer with manual gearbox replacement
- 3.5. Rotary tillers F-G-KAPPA: reducer with gearstick
- 3.6. Adjustment of working depths
- 3.7. Rotary tillers E-F-G-KAPPA: use of the seeder attachment
- 3.8. Rotary tillers D-E-F-G-KAPPA: use with ploughing peg teeth
- 3.9. Rotary tillers F-G-KAPPA: use with Subsoiler
- 4.1 Transport
- 4.2 Maintenance and repair
- 5 Warranty
- 6 Rules to observe to order spare parts correctly
- 7 Safety pictogrammes

### 1. GENERAL INDICATIONS

**1.1. Manufacturer:** **FALC S.r.l.**  
via Proventa n.41 - Faenza (Ravenna) - ITALIA -  
Tel. ++39 0546 29050  
Fax ++39 0546 663986  
e-mail: [info@falc.eu](mailto:info@falc.eu)  
[www.falc.eu](http://www.falc.eu)

**1.2. Series: Rotary tillers A – B – C – D – E – F – G – KAPPA**

**1.3. Models:**

**1.4. Serial Number:**

#### **N. B.:**

- THIS INSTRUCTION MANUAL MUST BE SUPPLIED WITH EACH UNIT OF THE ABOVE MENTIONED SERIES.
- THE MACHINE OPERATOR IS OBLIGED TO READ IT IN ALL ITS PARTS IN ORDER TO UNDERSTAND THE MACHINE'S CORRECT OPERATION.
- **SAFETY NOTES AND NOTES OF PARTICULAR IMPORTANCE ARE HIGHLIGHTED IN BOLD.**
- **THE USER THAT MUST INTERVENE ON THE MACHINE WITH PARTICULAR OPERATIONS, WHOSE SPECIFIC INSTRUCTIONS HAVE NOT BEEN SUPPLIED, MUST REQUEST THEM DIRECTLY FROM OUR SALES OR TECHNICAL OFFICE.**

## **2. CONDITIONS FOR THE OPERATOR**

During use of the rotary tiller, the operator must stay on the tractor in the driver's position. The operator cannot leave the driver's position on the tractor if he hasn't disengaged the power take-off from the tractor itself and has not waited for the moving parts of the rotary tiller (rotor, etc.) to come to a complete standstill.


In normal conditions, that is, with the rear lid closed, the operator must ensure that when starting up the rotary tiller and during its operation, there are no persons within a radius of 5 m around the machine.

The operator must immediately stop the tractor as well as the rotary tiller if one or more persons enter within a 5 m radius around the machine.

The operator cannot activate the tractor's lifting device without first disconnecting the power take off. Before lifting the rotary tiller from the ground using the tractor's lifting device, the operator must ensure that the power take off is disconnected.

### **3.1 GENERAL CONDITIONS OF USE**

FALC rotary tillers are built to be coupled to an ideal tractor provided with a 3-point hitch and a Cardan shaft transmission. The rotary tillers are used to refine the soil and prepare it for sowing. On all rotary tiller produced by FALC, it is possible to replace the traditional hoe rotor with a straight cutters rotor (Terraking) or with a toothed rotor (Rotoking)



The use of the Rotoking rotor is recommended for particularly heavy, difficult or stony soils; the special shape of the tooth and its specific inclination make it so that even the hardest sods are "attacked" and do not escape the teeth in operation; breaks the ground, is ideal for the destruction of herbs cultivations or old lawns, breaks and buries stubble that remains after harvest and the waste of previous cultivations; does not cause the formation of the smooth impermeable layer; is ideal for working vineyards and fruit orchards in general.

**EVERY OTHER USE OF THE ROTARY TILLER AND THE APPLICATION TO THE SAME OF ACCESSORIES NOT MANUFACTURED BY FALC IS TO BE CONSIDERED ILLEGAL AND NOT PERMITTED BY THE MANUFACTURER.**



To prevent toppling risks, the tractor to be linked to the rotary tiller must be chosen taking into account the weight of the apparatus (kg). The tractors must moreover be chosen with a power to suit the rotary tiller's size. The tractor's power values recommended by FALC are the following:

| Model          | Weight<br>kg | Tractor<br>Hp |
|----------------|--------------|---------------|
| A 900          | 160          | 15-30         |
| A 1100         | 170          | 15-30         |
| A 1250         | 180          | 15-30         |
| A 1450         | 190          | 15-30         |
| A 1650         | 200          | 15-30         |
| BS 900         | 195          | 20-50         |
| BS 1100        | 224          | 20-50         |
| BS 1250        | 234          | 20-50         |
| BS 1450        | 246          | 20-50         |
| BS 1550        | 266          | 20-50         |
| BS 1650        | 276          | 20-50         |
| BS Super 1250  | 245          | 20-55         |
| BS Super 1450  | 255          | 20-55         |
| BS Super 1650  | 290          | 20-55         |
| BS Super 1800  | 300          | 20-55         |
| Cultiline 1300 | 570          | 40-65         |
| Cultiline 1600 | 620          | 40-65         |
| C 1300         | 385          | 40-65         |
| C 1600 Super   | 440          | 40-80         |
| C 1800 Super   | 470          | 40-80         |
| C 2100 Super   | 510          | 40-80         |
| C1 1300        | 375          | 40-70         |
| C1 1500        | 395          | 40-70         |
| C1 1600        | 415          | 40-70         |
| C1 1800        | 445          | 40-70         |
| C1 2100        | 475          | 40-70         |

| Model      | Weight<br>kg | Tractor<br>Hp |
|------------|--------------|---------------|
| CS 1300    | 380          | 40-70         |
| CS 1500    | 400          | 40-70         |
| CS 1600    | 420          | 40-70         |
| CS 1800    | 450          | 40-70         |
| CS 2100    | 480          | 40-70         |
| D1 1800    | 585          | 60-100        |
| D1 2100    | 635          | 60-100        |
| D1 2300    | 695          | 60-100        |
| D1 2500    | 745          | 60-100        |
| D 1800     | 590          | 60-100        |
| D 2100     | 640          | 60-100        |
| D 2300     | 700          | 60-100        |
| D 2500     | 750          | 60-100        |
| E 2500     | 1130         | 60-120        |
| E 3000     | 1250         | 60-120        |
| F 2500     | 1200         | 80-140        |
| F 3000     | 1400         | 80-140        |
| G 2500     | 1520         | 120-220       |
| G 3000     | 1680         | 120-220       |
| G 3500     | 1950         | 120-220       |
| G 4000     | 2100         | 120-220       |
| G 4500     | 2300         | 120-220       |
| Kappa 4000 | 2630         | 190-300       |
| Kappa 4500 | 2970         | 190-300       |
| Kappa 5000 | 3310         | 190-300       |
| Kappa 6000 | 3520         | 190-300       |

To check the lifting capacity and stability of the tractor, the following conditions must be respected:

$$M \times s \leq 0,2 T \times i + Z (d + i)$$

$$M \leq 0,3 T$$

i = distance between tractor wheels


T = tractor weight

d = distance of the front axis from the ballast

Z = ballast weight

s = start from the rear axis of the shredder

M = weight



**IT IS PROHIBITED TO TAKE ON BOARD AND TRANSPORT PERSONS, ANIMALS OR OBJECTS ON ALL ROTARY TILLERS PRODUCED BY FALC.**

### **3.2. CONNECTION OF THE ROTARY TILLER TO THE TRACTOR**

- 1) All Falc rotary tillers can be applied to any type of tractor as long as it is supplied with 3-pin universal attachment.
- 2) The rotary tiller must be positioned on the level and in a stable position.
- 3) The tractor must reverse towards the rotary tiller until its arms correspond with the arms of the 3p rotary tiller. During this phase, any pedestrian operator must be at least 5 mt from the machine.
- 4) Position the plugs of the lower 3 pins and block them using the supplied cotter pins.
- 5) Connect the upper tractor arm to the upper pin of the 3-pin, adjusting it in a way that the machine takes on a horizontal position with respect to the ground.
- 6) Position the propeller shaft and check that its ends are well coupled with the tractor's and intensifier's power take off. Fix the anti-rotation chains present on the drive shaft both on the tractor side and on the rotary tiller side. **During this phase the tractor engine must be switched off, to prevent an incorrect manoeuvre from activating the Power take off (PTO).**
- 7) After having carried out these operations, it is possible to activate the tractor lifting device to release the support feet (if present), which must be completely raised and blocked using the supplied pins.
- 8) **NORMAL SUPPLY:**
  - Power take off (PTO) of the tractor = 540 revs/minute for Models A-B-C-D
  - Power take off (PTO) of the tractor = 540/1000 revs/minute for Models E (check the couple of gear boxes mounted in the reducer)
  - Power take off (PTO) of the tractor = 1000 revs/minute for Models F-G-Kappa
- 9) If the land has masses, stones or anything else that may cause a blow to the hoes, the use of propeller shafts with clutch or with other safety systems (shear Bolt Torque Limiter or Automatic Torque Limiter LR) is indispensable. It is also advised to let the motor tick over at low revs, in a way to soften blows to a maximum. Any problems caused by working on particularly rocky land will not be covered by the warranty. The calibration of the cardan joint clutch must also be checked to be sure that it carries out its function correctly. It is advised to carry out this control at a specialised centre. The clutches on the propeller shaft normally supplied by Falc, are calibrated to the maximum available load. It is advised to have the propeller shaft clutch controlled by a specialist every 300 working hours or, if the work is seasonal, on re-starting activity after the break.



### **3.3. DISCONNECTION OF THE ROTARY TILLER FROM THE TRACTOR**

The arrangements necessary for correct disconnection of the rotary tiller from the tractor are the following:

- 1) Stop the tractor on level ground, activate the handbrake and remove the power take off.
- 2) Rest the rotary tiller on the ground in a way that it is stable and horizontal.
- 3) Switch the tractor engine off.
- 4) Disconnect the cardan joint from the tractor's power take off.
- 5) Disconnect the rotary tiller from the 3-point hitch of the tractor first by sliding out the split pins that block the dowels and then by removing the pins themselves.
- 6) Climb onto the tractor again and move it forward to completely free the tractor's arms from the 3rd point of the rotary tiller.

### **3.4. ROTARY TILLERS C-D-E: REDUCER WITH MANUAL REPLACEMENT OF THE GEAR BOXES**

The C-CS-D-E series have a reducer with manual gear box replacement mounted on them. It is therefore possible to vary the gear ratio depending on the operator's specific requirements.

**MANUAL REPLACEMENT OF THE GEAR BOXES IN THE REDUCER CAN ONLY BE CARRIED OUT IF THE ROTARY TILLER IS NOT CONNECTED TO THE TRACTOR'S POWER TAKE OFF.**

The operations for gear box replacement are the following:

- 1) Stop the tractor with the rotary tiller attached on level ground, activate the handbrake and disconnect the power take off.
- 2) Get off of the tractor and disconnect the cardan joint from the tractor's power take off.
- 3) Wait for the reducer to cool before touching it. Cooling time depends on previous use of the rotary tiller before stopping and also atmospheric conditions.
- 4) After having ensured that the reducer is cold, unscrew the outlet plug and collect the oil that runs out in an adequate container.
- 5) ATTENTION: do not dispose of this oil in the environment.
- 6) Remove the rear cover and pay attention not to damage the seal.
- 7) Replace the mounted gear boxes with those stocked scrupulously following the diagram shown on the label supplied with every rotary tiller (if in doubt about the positioning of the gear boxes, refer to the area's authorised dealer or Falc sales office directly).
- 8) Position the replaced gear boxes in the relevant seats in the cover (excluding rotary tiller E) and block them carefully.
- 9) Remount the cover, the relative seal, place the screws and position the outlet plug.
- 10) Use the inlet plug to replace the oil previously removed and check the level.

### **3.5. ROTARY TILLERS F-G-KAPPA: REDUCER WITH GEARSTICK**

The rotary tillers of the F-Kappa series have a reducer with 3-speed gearstick.

The rotary tillers of the G series have a reducer with 2-speed gearstick

To change the rotation speed of the rotor follow the indications below:

- 1) Stop the tractor on level ground with the rotary tiller attached, activate the handbrake and disconnect the power take off.
- 2) Get down from the tractor and remove the cardan joint from the tractor's power take off.
- 3) Wait for the reducer to cool down before touching it. The cooling time depends on the previous use of the rotary tiller and atmospheric conditions.
- 4) Activate the gearstick to insert the desired gear ratio.

The possible speeds that can be obtained with the gearstick are stated on the label applied to every rotary tiller. If in doubt about the speed inserted, refer to the area's authorised dealer or Falc sales office directly.


### **3.6. ADJUSTMENT OF WORKING DEPTHS**

**Before using the rotary tiller it is necessary to supervise working depth adjustment in a particular manner.**

**Adjustments can only be made when the machine is stopped and the Cardan joint is not connected to the tractor's power take-off.**


#### **Rotary tillers D-E-F-G-Kappa with roller or wheels:**

The working depth is adjusted by positioning the 2 dowels in the holes of the machine's fixed side panels, in such a way as to block the movement of the rear roller or of the wheels (**pos.A**). The arms can be completely blocked by using the second dowel furnished (**pos.B – A requested**).



#### **Rotary tillers C with rear roller:**


The working depth is adjusted by means of a handwheel fixed to the upper part of the rotary tiller and to the roller's frame





### **Rotary tillers A-B-C-D-E-F-G with skids:**

The working depth is adjusted by moving the skids by one or more positions with respect to the side to which they are bolted. It is recommended to position the skids always at the same height so as not to have a different working depth between one side of the rotary tiller and the other.



### **Together with working depth adjustment it is opportune also to adjust the rear bonnet.**

Rotary tillers A-B-C: it is possible to adjust the height of the rear bonnet by lengthening or shortening the carrying chain.

Rotary tillers C-D-E-F-G-Kappa: it is possible to adjust the height of the rear sump by moving the arm with shock absorber spring by one or more positions.

The position of the rear bonnet determines the good result of working:

- 1) Dry lands: to obtain the best breaking-up of the land and perfect levelling, the bonnet must be lowered and kept near to the hoes.
- 2) Damp, wet or clayey land: to prevent flooding the bonnet must be raised and kept as far away as possible from the hoes

**The adjustments can only be carried out when the machine is at a standstill and the cardan joint is not connected to the tractor's power take off.**


### **3.7. ROTARY TILLERS E-F-G-KAPPA: USE OF THE SOWER HITCH**

- The E-F series rotary tillers are predisposed to utilise both a mechanical and an hydraulic sower hitch.
- The G-Kappa series rotary tillers are predisposed to utilise an appropriate hydraulic sower hitch.

**The various types of sower hitches manufactured by FALC can only be utilised if linked to machines manufactured by FALC. Even if sold separately as accessories, they absolutely cannot be linked to other types of machines. Improper use of a sower hitch produced by FALC, will be considered illegal and not permitted by the manufacturer.**

The sower hitch, mechanical as well as hydraulic can be supplied already mounted on the machine or as an accessory to be applied by the end user. It is anyhow recommended to always consult a service centre, or directly FALC's commercial or technical departments if one intends mounting a sower hitch on an existing rotary tiller.

The sower hitch, mechanical as well as hydraulic, is fixed to the rotary tiller's 3rd point in 3 positions (A) by means of dowels and relative split pins..




To mount the sower hitch, follow these operations:

- 1) Stop the tractor and the rotary tiller on plane ground, activate the handbrake, switch the tractor off and ease the rotary tiller on the ground taking care that it maintains a plane configuration with respect to the ground.
- 2) Disengage the tractor's power take-off.
- 3) Climb off the tractor, disconnect the Cardan shaft from the tractor's power take-off and place it in the relative support.
- 4) Lift the sower hitch with suitable lifting apparatus and place it in correspondence of the hitches located on the rotary tiller's 3rd point.

**ATTENTION: if suitable apparatus is not available to carry out this operation, it is recommended to always consult a FALC service centre or a specialised workshop.**

- 5) Position the dowels and block them with the split pins.

In transport conditions, namely, with the hydraulic sower hitch positioned, it is compulsory to fix the safety dowel (A) in correspondence of the holes provided on the upper part of the rotary tiller's 3rd point.



The sowing machine must be placed in location of the 2 hooks (B) and of the adjustable tierod (C).

If the sowing machine is to be connected to the rotary tiller's gearbox by means of the Cardan joint, the plastic output shaft cover on the rear side of the gearbox itself must be removed and replaced with an appropriate cover which is supplied on request.

**THE COVER OF THE ROTARY TILLER'S GEARBOX'S THROUGH SHAFT CAN ONLY BE REMOVED IF A CARDAN SHAFT CONNECTION WITH A SOWING MACHINE IS TO BE CARRIED OUT.**



As soon as the junction between the rotary tiller's gearbox and the sowing machine is disconnected, it is obligatory to reposition the cover of the through shaft.

As already highlighted, the installation of the sower hitch, the sowing machine and the connection between rotary tiller and sowing machine by means of a Cardan shaft can only be carried out if the tractor and the rotary tiller are NOT connected by Cardan joint.

**Connection of the hydraulic seeder attachment:**

Rotary tillers E-F-G: Hydraulic Seeder Attachment with 1 piston

Rotary tiller G-KAPPA: Hydraulic Seeder Attachment with 2 pistons (with adjustable arms)


The seeder attachment is complete with hydraulic pipes with automatic coupling for connection with the control unit on the tractor. By activating the hydraulic control unit lever, movement of the seeder attachment and seeder is obtained.

During the movement phases of the sower hitch and of the sowing machine, the operator must ensure that there are no persons, animals or things within a radius of 5 m around the machine.

If the operator uses the Hydraulic Seeder Attachment for the first time, he is advised to practice movements made possible by the pistons before starting work.

**3.8. ROTARY TILLERS D-E-F-G-KAPPA: USE WITH ADJUSTABLE TRACE BREAKER.**

One or more adjustable trace breaker can be applied to the front pipe of the rotary tiller's framework by means of threaded clips. Normally, the ploughing peg teeth are positioned in couples close to the tractor wheels.



### **3.9. ROTARY TILLERS F-G-KAPPA: USE WITH SUBSOILER**


In order to reduce production costs, it is possible to apply a subsoiler in front of the rotary tillers to “break” the ground in depth. The subsoiler is provided with suitable hitches for application to the rotary tiller and to the tractor’s rear arms

**It is necessary to dispose of suitable lifting means to apply the subsoiler to the rotary tiller. If suitable lifting apparatus is not available to apply the subsoiler to the rotary tiller’s 3rd point, it is compulsory to consult a FALC service centre or a specialised workshop.**

The weights of the subsoilers are the following:

Subsoiler 3000 = kg 490

Subsoiler 4000 = kg 670



### **4.1 TRANSPORT**

During operation the rotary tillers rest nearly on the roller, on the lateral slides and, in some cases, also on wheels. They are lifted by the tractor arms at the front.

During transport, rotary tillers are supported completely by the tractor (see Point 3.1).

For movement, made necessary for loading, unloading and storage, always use equipment that is suitable for the weight of the machine and use the pegs that are positioned on the machine.

As a result of the space taken up during transport, it may be necessary to dismantle the side and front guarding furnished. In this case, the guarding will be placed in a very evident manner on the machines onto which they will have to be remounted; it will be the responsibility of the receiver to provide for their positioning. In order to correctly position the side and front guarding simply consult the spare parts table related to the specific type of rotary tiller. The guards are supplied complete of their fixing nuts and screws. If in doubt, contact the area service centre or directly FALC’s sales or technical departments.



## **4.2 MAINTENANCE AND REPAIRS**

**Before approaching the machine to carry out any maintenance or repairs, it is compulsory to take some precautions:**

- 1) **Stop the tractor on level ground**
- 2) **Ease the rotary tiller on the ground**
- 3) **Activate the handbrake**
- 4) **Disengage the power take-off**
- 5) **Turn the engine off.**

**In case of specific maintenance or repair where it is necessary to lift the machine from the ground or rotate it, it is indispensable to use suitable equipment built for such purposes. It is always recommended to consult the area sales assistance or mechanical workshops ideally equipped.**

**The machines' weights are reported in point 3.1. of this manual.**

**Wait for very hot machine parts, such as the reducer, bearings, chains, etc. to cool, before carrying out any interventions. The cooling time for these parts depends on the previous work carried out and external atmospheric conditions.**

### **4.2.1 Maintenance**

|                           |                      |                             |
|---------------------------|----------------------|-----------------------------|
| Lubricants used           |                      |                             |
| Rotary tiller A-B-C-D     | Reducer              | MobilGear 634 Oil - SAE 140 |
|                           | Lateral transmission | EP1 Grease                  |
| Rotary tiller E-F-G-KAPPA | Reducer              | MobilGear 634 Oil - SAE 140 |
|                           | Lateral transmission | MobilGear 634 Oil - SAE 140 |

Even though all the rotary tillers are delivered well greased and lubricated, hereafter is a list of rules which must strictly be adhered to, so as to obtain the best results.

- 1) **After the first hour of operation**
  - Check that all bolts and screws are correctly tightened.
- 2) **Daily**
  - Check the oil level in the transmission box
  - Check the oil level of the lateral transmission (both with chains and gear boxes).
  - Lubricate the cardan joint (see the specific instruction book relative to the drive shaft).

**ATTENTION:** the Cardan joint is in general supplied by FALC and is suitable for the effective power required for the tractor-shredder link-up. In case of replacement always use a Cardan joint with characteristics not inferior to those of the original Cardan shaft.
- 3) **Every 8 working hours**
  - Lubricate rotor bearings using the relevant greasers that are indicated on the machine. Grease moderately introducing a small amount of grease at a time.
  - Grease all points indicated on the machine.
- 4) **Every 8 working hours – For rotary tillers with secondary chain drive**
  - Check chain tension to prevent rapid wear of the chain and relative gear boxes.
- 5) **Every 300 working hours**
  - Change the oil in the transmission box and in the side transmission.
  - Check that the reducer vent cap is not blocked internally with dust or earth.

If in doubt replace the vent cap.

ATTENTION: the used oil must not be discharged into the natural environment, but consigned to bodies authorised for collection and subsequent disposal.

- 6) If vibrations are felt during working, STOP THE ROTARY TILLER IMMEDIATELY AND DISCONNECT THE POWER TAKE OFF. Check for any breakage or excessive wear of the knives or teeth.
- 7) Also check if there are residues or deposits on the knives, on the teeth or on the rotor. If positive, have them cleaned.
- 8) It is advised to clean the machine well and move any residues that have accumulated during working before a period of inactivity. During this period protect the machine from atmospheric agents.

#### 4.2.2 Rotary tillers A-B-C: checking the tension of the side transmission chain

The chain tension can only be checked if the rotary tiller is not connected to the tractor's Power Take-Off with the Cardan joint.


It is hence prohibited to approach the side transmission if the machine is connected to the tractor's Power Take-Off with the Cardan joint.

To check for the correct tension of the chain, the operations are as follows:

- 1) Loosen the counternut (B).
- 2) Screw with in the adjustment screw (A) with a screwdriver or special spanner.

ATTENTION: If the chain is too loose or too tight, it can cause breakages on various mechanical components of the rotary tiller.

If in doubt or difficulty in adjusting the chain, contact the area service centre or directly FALC's sales or technical departments.





## **5. WARRANTY**

- a) Warranty period is fixed at 1 year from delivery. The company commits itself to replace parts which might present material or construction defects, in the least time possible. Labour time necessary for the replacement is excluded from the warranty. Transport and/or dispatch expenses are also excluded from the warranty.
- b) The buyer loses the warranty right if the faults are derived from force majeure, from an incorrect use of the machine or from any wrong action on behalf of the buyer, his employees or third parties. Repairs, replacements and modifications carried out or made to carry out by the buyer without the manufacturing company's authorisation are included among these actions. An incorrect use of the machine is the result of absence of adherence to the operating instructions listed in this manual.
- c) Parts which due to their nature or function are subject to inevitable wear and tear or strain, are excluded from the warranty.
- d) Bearings and oil seals are excluded from the warranty.
- e) The Cardan shaft is excluded from the warranty.
- f) The following rules are applicable to the parts for which warranty is intended:
  - the part to be replaced must be returned to the company on request of the new part.
  - the spare parts will always be invoiced on dispatch.
  - **only the examination of the part on behalf of the manufacturing company's technicians could give the right to recognition of the warranty and hence a right to the credit.**

## **6. RULES TO OBSERVE TO ORDER SPARE PARTS CORRECTLY**

To obtain a speedy dispatch of spare parts orders, it is necessary to specify:

- a) Machine type, Model, Serial Number.  
(e.g. ROTARY TILLER G 3000 S.N. XXXXX)
- b) Spare parts table number where the part in question is located, Identification Number, Part code.  
(e.g. Table no. YY, Detail no. JJ, Code KKKKKK)
- c) Exact name of the detail.
- d) Quantity of pieces requested.
- e) Dispatch instructions.  
(by rail, parcel post, courier, etc.)
- f) The minimum delivery time of the requested parts is 3 days from receipt of order


**IF ANY PART OF THIS INSTRUCTION MANUAL SHOULD RESULT INSUFFICIENTLY CLEAR, WE ASK YOU TO KINDLY CONTACT YOUR CLOSEST AUTHORISED DEALER OR CONTACT US DIRECTLY AT OUR TECHNICAL AND COMMERCIAL DEPARTMENTS.**

This handbook or any part of it cannot be reproduced, copied or published without prior written authorization of FALC.

FALC reserves the right to modify the here described specifications at any time without committing itself to update this handbook every time.

**Label no.1**


**ATTENTION** : Read the instruction manual before using the machine.



**Label no.2**

**ATTENTION** : Danger of hand and fingers collision with movements in alternate rotation.


Keep the safety distance.



**Label no.3**

**ATTENTION** : Danger of foot collision with movements in alternate rotation.


Keep the safety distance.



**Label no.4**

**ATTENTION** : Danger for feet due to rotating cutters with horizontal rotating axis.

Keep the safety distance.






**Label no.5**

**ATTENTION :** Danger due to machine component that can be lifted from the ground.

Keep the safety distance.




**FALC** FAENZA (RA) - ITALY - TEL. 0546/29050 - FAX 0546/550866

5

**Label no.6**

**ATTENTION :** Danger of cutting due to moving parts.

Wait until all moving components are completely still before approaching the machine.




**FALC** FAENZA (RA) - ITALY - TEL. 0546/29050 - FAX 0546/550866

6

**Label no.7**

**ATTENTION :** Danger due to flying objects.

Keep the safety distance.




**FALC** FAENZA (RA) - ITALY - TEL. 0546/29050 - FAX 0546/550866

7

**Label no.8**

**ATTENTION :** Danger due to hot surfaces.

Keep the safety distance.




**FALC** FAENZA (RA) - ITALY - TEL. 0546/29050 - FAX 0546/550866

8

**Label no.9**

**ATTENTION** : Danger of hand and finger cutting.  
Keep the safety distance.




**FALC** FAENZA (RA) - ITALY - TEL. 0546/29050 - FAX 0546/550866

9

**Label no.10**

**ATTENTION** : Danger of feet cutting.  
Maintain the safety distance.




**FALC** FAENZA (RA) - ITALY - TEL. 0546/29050 - FAX 0546/550866

10

**Label no.11**

**ATTENTION** : Danger of rotating movements.  
Do not open or remove the safety guards of the rotating shafts while the machine is in operation.



**FALC** FAENZA (RA) - ITALY - TEL. 0546/29050 - FAX 0546/550866

11

**Label no.12**

**ATTENTION** : Danger due to loads lifted from the ground.  
Keep the safety distance.





**FALC** FAENZA (RA) - ITALY  
TEL. 0546/29050 - FAX 550866

12



## Italiano: Istruzione per il montaggio del cardano

|   |  |   |
|---|--|---|
| <p>Prima di montare il cardano, leggere attentamente il Libretto fornito dal costruttore del cardano stesso.<br/>La Ditta Falc Srl declina ogni responsabilità per operazioni effettuate sul cardano senza seguire le Istruzioni specifiche fornite dal costruttore del cardano stesso.</p> | <p>Prima di iniziare a lavorare, si raccomanda di verificare la lunghezza del cardano:<br/>se è LUNGO, alzando o abbassando la macchina, le 2 parti telescopiche si accoppieranno completamente creando pressione sulle crociere e sulle forcelle; se è CORTO, alzando o abbassando la macchina, le 2 parti telescopiche si sfileranno troppo.</p> | <p>Le macchine agricole portate sono collegate direttamente al trattore e posizionate mediante attacco a tre punti. Generalmente con attrezzo in lavoro (a) si ha la configurazione di minore lunghezza dell'albero ed angoli di snodo sensibilmente uguali. Ad attrezzo sollevato (b) si ha la massima estensione dell'albero, l'aumento e la diversificazione degli angoli di snodo. Durante il sollevamento è <b>INDISPENSABILE</b> interrompere la rotazione del cardano.</p> |
|---|--|---|



## Français: Instructions pour le montage de l'arbre à cardan

|  |  |   |
|--|--|---|
| <p>Avant de monter le cardan, lire attentivement le Livret fourni par le fabricant du cardan lui-même.<br/>L'entreprise Falc Srl décline toute responsabilité pour toute opération effectuée sur le cardan sans avoir suivi les instructions spécifiques fournies par le fabricant de ce cardan.</p> | <p>Avant de commencer à travailler, nous recommandons de vérifier la longueur du cardan :<br/>s'il est LONG, en relevant ou en baissant la machine, les deux parties télescopiques vont s'accoupler complètement en exerçant une pression sur les tourillons et les fourchettes ; s'il est COURT, en relevant ou en baissant la machine, les 2 parties télescopiques risquent de se désenfiler trop.</p> | <p>Les machines agricoles portées sont connectées directement au tracteur et mises en place par l'attelage à trois points.. Avec l'outil en fonction (a) la configuration du cardan est de longueur minimum et les angles d'articulation sont similaires. Lorsque l'outil est soulevé (b), l'extension du cardan est au maximum et on a l'augmentation et la diversification des angles d'articulation. Pendant le soulèvement il est <b>INDISPENSABLE</b> d'interrompre la rotation du cardan.</p> |
|--|--|---|

## English: Instructions for the assembling of the cardan shaft

|   |  |  |
|---|--|--|
| <p>Before mounting the cardan shaft, carefully read the booklet supplied by the Manufacturer.<br/>Falc Srl declines all responsibility for operations carried out on the cardan shaft if the specific instructions supplied by the Manufacturer are not followed.</p> | <p>Before starting work, it is advised to check the length of the cardan shaft:<br/>if it is LONG, by raising or lowering the machine, the 2 telescopic parts will couple completely, creating pressure on the cross and on the forks;<br/>if it is SHORT, by raising or lowering the machine, the 2 telescopic parts will slide apart too much.</p> | <p>The agricultural machinery carried is connected directly to the tractor and positioned using a three-point attachment. Generally, when the equipment is functioning (a) the shorter length of the shaft with equal articulation angles is present. With the equipment raised (b) there is maximum extension of the shaft, increase and diversification of the articulation angles. During lifting it is <b>INDISPENSABLE</b> to interrupt rotation of the cardan shaft.</p> |
|---|--|--|

## Deutsch: Bedingungen für die Gelenkwellenanbau

|   |  |   |
|---|--|---|
| <p>Bevor Sie die Kardanwelle montieren, ist das vom Hersteller der Kardanwelle gelieferte Handbuch aufmerksam durchzulesen.<br/>Falc Srl haftet nicht für an der Kardanwelle durchgeführte Arbeiten, bei denen die spezifischen Anweisungen des Herstellers der Kardanwelle nicht eingehalten wurden.</p> | <p>Vor dem Beginn der Arbeiten ist die Länge der Kardanwelle zu überprüfen.<br/>Falls die Kardanwelle LANG ist, kuppeln die beiden Teleskopteile bei Heben oder Senken vollständig ein und drücken auf das Gelenkkreuz und das Gabelgelenk.<br/>Falls die Kardanwelle KURZ ist, fahren die beiden Teleskopteile bei Heben oder Senken zu sehr aus.</p> | <p>Die Anbau-Landmaschinen werden direkt an den Traktor angeschlossen und mit einem Dreipunktanschluss positioniert. Im Allgemeinen sind im Fahrzustand der Maschine (a) die Welle kürzer und die Gelenkwinkel annähernd gleich. Bei gehobener Maschine (b) ist die Welle maximal ausgefahren; die Gelenkwinkel sind größer und unterscheiden sich voneinander. Während des Hubs MUSS die Rotation der Welle unterbrochen werden.</p> |
|---|--|---|

## Español: Instrucciones para el montaje de la cardan

|  |   |   |
|--|---|---|
| <p>Antes de montar el cardan, leer detenidamente el Manual suministrado por el fabricante de éste.<br/>La empresa Falc Srl se exime de cualquier responsabilidad frente a operaciones que puedan efectuarse en el cardan sin cumplimiento de las instrucciones específicas dictadas por el fabricante del mismo.</p> | <p>Antes de iniciar a trabajar, se recomienda comprobar que la longitud del cardan sea la adecuada:<br/>Si es demasiado LARGO, al alzar o descender la máquina sus 2 partes telescópicas se acoplarán completamente, creando presión en las crucetas y en las horquillas.<br/>Si es demasiado CORTO, al alzar o descender la máquina sus 2 partes telescópicas se desengancharán excesivamente.</p> | <p>Las máquinas agrícolas traídas están directamente unidas al tractor por medio de un enganche de tres puntos. Generalmente, cuando el equipo está en posición de trabajo (a) se obtiene una configuración con una menor longitud del árbol y con ángulos de articulación muy parecidos. Con el equipo en posición alzada (b) se obtiene la extensión máxima del árbol, con un aumento de los ángulos de articulación, que ahora serán distintos entre si. Durante la elevación es INDISPENSABLE interrumpir la rotación del cardan.</p> |
|--|---|---|

## Nederlands: Instructies voor montage van de aftakas

|   |  |  |
|---|--|--|
| <p>Lees de door de fabrikant geleverde handleiding aandachtig door alvorens de aftakas te monteren.<br/>Falc Srl wijst elke aansprakelijkheid af als de betreffende specifieke montageaanwijzingen niet worden opgevolgd.</p> | <p>Controleer eerst de lengte van de aftakas alvorens met de montage-werkzaamheden te beginnen.<br/>Als de aftakas TE LANG is, schuiven de beide telescopische delen volledig in tijdens het heffen en dalen van het werktuig en wordt druk uitgeoefend op de kruiskoppeling en de vorken;<br/>Als de aftakas TE KORT is, schuiven de beide telescopische delen tijdens het heffen en dalen van het werktuig te veel uit elkaar.</p> | <p>Aanbouwmachines worden bevestigd aan de driepuntkoppeling van de tractor.<br/>In het algemeen geldt dat als het werktuig in bedrijf is (a) de korter is en de knikhoek gelijk. Met het werktuig in geheven positie (b) is de as maximaal uitgeschoven, en is de knikhoek groter en variabel. Als het werktuig wordt geheven MOET de aftakas worden uitgeschakeld.</p> |
|---|--|--|

## Dansk: Montage af kardanaksel

|   |   |   |
|---|---|---|
| <p>Før montagen af kardanakslen påbegyndes, gennemlæses producentens brugervejledning grundigt.<br/>Falc Srl er fritaget for ethvert ansvar i forbindelse med arbejder foretaget på kardanakslen, hvis de givne retningslinier, som er specificeret af producenten, ikke er fulgt nøje.</p> | <p>Før arbejdet påbegyndes, anbefales det at kontrollere kardanakslens længde ved at hæve eller sænke redskabet.<br/>Hvis den er for LANG, resulterer det i, at de to kardan dele støder sammen, når redskabet er i sin yderposition, hvilket bevirker et ødelæggende tryk på kardankryds og transmissioner.<br/>Hvis den er for KORT, resulterer det i, at de to kardan dele kan glide fra hinanden, hvilket bevirker, at de ikke er i indgreb med hinanden.</p> | <p>Redskabet monteres direkte på traktorens 3-punktsophæng. Generelt gælder, at når redskabet er sænket (a), er kardanakslen i sin korteste position, og når redskabet er hævet (b), er kardanakslen i sin længste position. Når redskabet hæves, SKAL kardanakslens rotation afbrydes.</p> |
|---|---|---|





